



LINOLIE & PIGMENT

Instruction manual – Plejeolie

IMPORTANT!

Cloths containing linseed oil can ignite spontaneously.

They should be removed immediately, dipped in a bucket of water or burned!

HOW TO APPLY OIL

When you start your oiling project, it is important that the wood does not already have a painted surface but appears porous and untreated, or the wood has previously been treated with oil.

STEP 1: Before oiling, the wood must be clean, which is ensured by washing the surface with a mixture of 32% vinegar diluted in water at a ratio of 1 part vinegar to 25 parts water.

STEP 2: Once the surface is dry, it can be sanded with 120 grit sandpaper. Sand lightly in the direction of the wood grain.

STEP 3: Next, apply the oil with a brush or sponge in a generous amount. Spread the oil on the surface and rub it well into the wood.

STEP 4: Let the oil work for 30-45 minutes.

STEP 5: Polish off excess oil with a clean cotton cloth until the surface appears completely dry and uniform. It is very crucial to polish off all oil within 60 minutes, as the oil begins to cure. It is important that there is no puddles of oil after polishing; the surface should appear dry. If the excess oil is not wiped off promptly, a thick 'honey-like' layer will form, making it impossible to proceed with further work.

STEP 6: If the windows are very needy, the above process can be repeated after 2-3 days.

